



4LUX™ QUICK START GUIDE

MOUNTING 4LUX

- Ensure the firearm is unloaded and pointed in a safe direction.
- Loosen the T-Nuts to adjust the gap to match the thickness of the mounting surface.
- Align the T-Nuts with the slot and insert in the desired location.
- An initial $\frac{1}{4}$ to $\frac{1}{2}$ turn of the screw for each T-Nut rotates the nut into engagement and then you may tighten normally.

NOTE: The M-LOK® direct attachment system features a custom-cammed T-Nut that positions the 4LUX consistently for installation and removal. The 4LUX requires 3 $\frac{1}{2}$ open M-LOK slots for proper mounting.



VISIT VIRIDIANWEAPONTECH.COM/4LUX TO LEARN MORE

4LUX™ QUICK START GUIDE

BATTERY INSTALLATION

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove battery door located at the bottom of the unit.
- Insert (2) CR2 batteries positive (+) side first, towards the top of the unit.
- Re-install battery door.

OPERATING 4LUX

- Grip the 4LUX with a normal shooting grip.
- Activate the 4LUX by pressing the button.



WARNING: The 4LUX metal front may become hot after prolonged use. Do not touch it while in use and allow to cool before handling directly.

VISIT [VIRIDIANWEAPONTECH.COM/4LUX](https://www.viridianweapontech.com/4lux) TO LEARN MORE

730-0149

